

SETTINGS FOR THE TITO DIP SWITCHES

For free play option the dip switches are set up as follows:

Both switches off – no free play



Switch 1 off and switch 2 on – 5,000 credits



Switch 1 on and switch 2 off – 1,000 credits



Both switches on – 10,000 credits



This will only be the case if you used standard credit options. If you have ordered custom options, the settings will go from lowest to highest following the pattern above.